Appropriate amount of flux can be applied to target points.







BON-102D Brush type (flat)



BON-102B Felt type (thin)



BON-102F Felt type (flat)



BON-102K Felt type (knife)

- All itmes are packed in 5 pcs per set.
- For your trial, Trial Kit (BON-102A, containing 7 different types) is available.
- BON-102L(long type) has been discontinued.
- * This is flux dispenser pen type container which is **empty** when shipment.

FEATURES

- This flux pen enables fine and accurate flux application.
- No flux evaporation. Flux density can be kept constant.

PURPOSE

- To apply flux to the workpieces before soldering work.
- To remove the oxidation film and to improve the solderability at repair process.
- To wash PCB by solutions such as alcohol.

Replacement parts BR-102 series Pen tip

BRUSH TYPE

Model	Dimension	Features
BR-102	φ4.3 14.0 1 2 3 1 2 3 1 3 1 3 1 3 1 3 1 3 1 3 1 3	For fine and precise point application

Model	Dimension	Features
BR-102T	φ <u>5.2</u> μ18.0	For fine point to large space application

Model	Dimension	Features
BR-102D	φ _{6.2} μ17.0	For large space application

Model	Dimension	Features
NEW BR-102S	φ2.5 1	Extra fine and precise point application

FELT TYPE

Model	Dimension	Features
BR-102B	φ4.5 9.5	For lubricator application

Model	Dimension	Features
BR-102F	φ4.5 10.0	For large space application

Model	Dimension	Features
BR-102K	φ 4.5 12.5	For point, line and large space application



For applying fluoric lubricant !!



- Felt type BON-102B, 102K and 102F are suitable for fine point application.
- Various shapes of pen tips are available such as Flat shape or Bullet shape.
- When you use special flux or solution, try small portion first.

Examples of other usage



Adhesive quickening method



Flux prevention material



Alcohol cleaning

BONPEN Trial kit BON-102A



BONPEN trial kit, **BON-102A** is renewed!

You can try every type of BONPEN. 7 pcs are packed

■ Contents

BON-102 / BON-102T BON-102D / BON-102B BON-102F / BON-102K

BON-102S